



## CRYPTIC

### 3 piece universal hubs

**Contents:** 4 hubs with hardware and bearings (6001, 12mm)

**1 hub Contains:** 2 hub shells  
1 black nylon centre bushing  
6 bolts M4 x 40 V2A  
6 nuts M4 V2A  
2 bearings 6001

#### Assembly:

1. Take out one Cryptic hub, and separate the two shells as shown
2. Insert the bearings, pushing them into the centre circles from the inside
3. Place the plastic bushing in the lower half
4. Place the tyre onto the lower shell (the one with the bushing on it), making sure the valve is aligned with the valve hole
5. Take the shell with the bolts still on it, align the valve holes and lower the shell onto the rest of the hub
6. Insert the nuts on the other side, and tighten them until a good resistance is found (do not over tighten or you won't be able to undo them)
7. Place the wheel onto your truck axle, making sure it goes through the metal spacer, and tighten the axle nut all the way, then untighten 1/8 turn

#### Tips:

- Don't over-tighten the axle nut, as this can tear your axle from the truck...not good
- Put a little bit of air in your tyres before assembling the hubs
- Don't worry about the hub twisting when you tighten up the bolts, this will eliminate itself as all the bolts are tightened up. You can avoid the twisting by doing each bolt a bit at a time.

**Enjoy riding with CRYPTIC hubs,  
FLAME-Mountainboards**

